

# **INSTALLATION INSTRUCTIONS – Rat Gaskets**

## **PLEASE READ BEFORE INSTALL!**

### **Installation**

Clean any carbon buildup or gasket material from the head. A razor blade or scotch britepad works well for this step. On each side of your Rat Gaskets apply a small bead of high-temp silicone around the exhaust ports. We recommend Permatex Ultra black. After installing your Rat Gaskets, starting in the middle and working your way out, torque the header bolts to 12-15 foot pounds. We strongly recommend not using stainless steel bolts.

Should you have any questions contact us:

Custom Exhaust Specialties, Inc.  
61533 American Loop, No. 3  
Bend, Oregon 97702  
541.330.5931  
Toll Free at 877.795.1802  
Fax 541.330.5931  
Email – [questions@cesonline.net](mailto:questions@cesonline.net)  
Website – [www.cesonline.net](http://www.cesonline.net)

Thank you.